

Fundamental Labs  
DC Motor Manufacture and Control

Prabhnoor Singh Sahni

January 28, 2024

# Contents

<b>1</b>	<b>Brushed Motor</b>	<b>2</b>
1.1	Bipolar Motor Building . . . . .	2
1.2	Rotational Speed Measurement . . . . .	2
1.2.1	Assignment K1,K2 . . . . .	4
<b>2</b>	<b>Brushless DC Motor</b>	<b>8</b>
2.1	Velocity Characteristics Measurement . . . . .	8
2.1.1	Assignment K3 . . . . .	8
2.1.2	Assignment K4 . . . . .	10
2.2	Feedback Based Control System Configuration . . . . .	11
2.2.1	Assignment K5 . . . . .	13
2.3	Using Motor as a generator . . . . .	16
2.3.1	Assignment K6 . . . . .	16
2.3.2	Assignment K7 . . . . .	17
2.3.3	Assignment K8 . . . . .	17
2.4	Conclusion . . . . .	20

# Week 1

## Brushed Motor

### 1.1 Bipolar Motor Building

In this section we will be building a DC motor. We begin by collecting the required parts as given to us in the manual. Then we make the encoder board by soldering the parts. Then we carefully cut pieces of the metal sheet to make the brush of the motor and finally we assemble the motor. After making sure that all the four brushes are properly touching the motor and the connections are not loose. We try to rotate the motor and we see that everything works.

### 1.2 Rotational Speed Measurement

First we make a semicircular disk and connect it to the motor, this will pass through the photointerrupter and will make it possible to determine the speed as we shall see later. Now we will connect the DC Motor Control Board to our setup. This board will measure the number of times the disk is crossing the photointerrupter and give us the number of rotations of the motor in 0.42 seconds. We confirm the operation of the board.

Now we also connect our oscilloscope to the circuit and set up our system for final measurement. We rotate the motor and begin taking measurements from oscilloscope as well as from the DC motor control board.

For the oscilloscope we set the time interval to 200 ms and measure the rpm. When we set our voltage to 15V, we look at the square waves on the oscilloscope and record the data. We measure the time interval and number of rotations. For 15V, we have 606.6 ms and 935.8 ms which gives us

$$\frac{(935.8 - 606.6) \text{ ms}}{4} = 12.2 \text{ rotations/s} = 729 \text{ rpm.}$$

We repeat this for 3 different voltage values corresponding to low (15V), medium (17V) and high (18V) and the results are in Table 1.1.

For 17V,

$$\frac{(516.2 - 437.6) \text{ ms}}{1} = 763.4 \text{ rpm},$$

for 18V,

$$\frac{(1041 - 924) \text{ ms}}{1} = 1025 \text{ rpm} \quad (1.1)$$

Then we count the number of rotations from the DC motor control board. On this board, we need to see the lights that are ON, which indicate 1 in binary. The steps are again repeated for the three voltages as in Table 1.1.

Table 1.1: Revolutions per minute (rpm) measured from motor control board and oscilloscope at different voltages

		Voltage		
		Small (15V)	Medium (17V)	High (18V)
<b>rpm</b>	Motor Control Board	1000 rpm	1571 rpm	1714 rpm
	Oscilloscope	729 rpm	763.4 rpm	1025 rpm

If we look at Table 1.1, we can see stark difference in the rpm measured from the oscilloscope and board. It is possible that the motor control board is inaccurate because it only takes into account integer values and this can cause discrepancies in our data. Now, in order to analyse our brushed motor a bit further, we need to look at the speed of the motor using brush timing adjustment. In our DC motor, we have brushes which need to make contact with the motor and change the direction of electric current in rotations. The timing of the brushes refers to the precise moment when the brushes switch the electrical current to different segments of the commutator and reverses the direction of current flow in the rotor windings and maintains continuous rotation. We aim to change this timing and see how the speed changes. To adjust the timing we change the position of the rotor notches, we loosen the screw and change the position of rotor notches with respect to a horizontal line. We do this for 5 different angles as in Table 1.2.

We can see in this table (Table 1.2) that we have maximum rpm of the motor at 0 degrees and 180 degrees (although the motor rotates in opposite direction). This angle is when the brushes are aligned with the neutral axis of the armature coil.

Table 1.2: Revolutions per minute corresponding to different positions of the rotor notch by adjusting angles

Angle	RPM
0°	2285.7
45°	2000
90°	0
135°	0
180°	-2285.7

### 1.2.1 Assignment K1,K2

#### K1 Brushed direct current motor

##### 1. Why brushed DC motors rotate and what is the role of brushes?

Let's look at Figure 1.1 which depicts the different stages of motor rotation. If we look at the first stage, the brush on the left touching the armature coil is in contact with the positive terminal and the brush on the other side is in contact with the negative terminal. Thus, current flows from left to right. Due to this a magnetic field is generated in the coil, which points to the left (from right hand rule). At this stage we can also see that the magnet is in such a position that the South pole of the magnet is close to the left coil and the north pole is close to the right coil. In such a scenario, we see from the figure that like poles are near each other, this would cause them to repel. Thus, there is a 90 degrees rotation in the clockwise direction and we get to the situation of the second stage.

Here, we can see that since our motor moved 90 degrees, the north pole is now near the left coil and south pole is near the right coil. Also look at the armature coil, we see that the coil has rotated; however, due to the structure of the metal sheet on the coil, the left brush is still in contact with the positive terminal and the right brush with the negative terminal. This maintains the direction of current and in turn the direction of poles on the coils. Thus, in this stage the north pole that has now reached the left coil is near the south pole and the south pole of the magnet that has reached the right coil is near the north pole. Opposite poles are now near each other! They will now attract, making the motor rotate in the same direction another 90 degrees. See Figure 1.1.

After a total 180 degree rotation, the third stage is a complete opposite of the first stage. The magnet's north pole is near the left coil and




Figure 1.1: The four stages of rotation for a brushed DC motor

south pole near the right. The armature coil has again rotated and now the left brush has come in contact with the negative terminal and right brush has come in contact with the positive terminal. This flips the direction of current. Since the direction of current has changed, the current going into the coil will be in different direction, this will cause the magnetic field produced to flip its direction as well. Thus, the coil's poles will flip. The north pole is now on the right and the south pole on the left. And due to this, the north pole of the magnet is near the north pole of the coil and the south pole of the magnet is near the south pole of the coil. This will again cause them to repel and they will again rotate another 90 degrees in clockwise direction. We see that even though the poles of the magnet are opposite, the rotation of the armature coil coupled with the flipping of current direction makes the rotation continue.

Finally, we move to stage 4, when the armature coil, the magnet and the motor as a whole have completed three quarters of rotation in the same direction. In this stage, the poles of the magnet are, north pole

near the right coil and south pole near the left coil. Now, even after rotation of the armature coil, it is still connected to the same terminals and the direction of current remains the same, just like we saw in the second stage. So, in this stage the direction of current is from right to left and therefore the poles of the coil are the same. Looking at Figure 1.1 we again see that opposite poles are near each other and they will attract. This will make the motor rotate another 90 degrees and thereby completing a full 360 degree rotation. This process continues for the motor's rotation.

We saw in this process how important the role of brushes was. Basically brushes play a role in reversing the direction of current after every half a rotation. Whenever, after a rotation of 180 degrees, the part of the armature coil that was connected to the left brush and the part that was connected to the right brush reverses its connection. Now they get connected to opposite brushes, making current direction change and in turn make magnetic field of coil change, thus making sure that motor rotation direction remains consistent. If the direction of current is not reversed by brushes the motor will rotate backwards i.e. after half a rotation clockwise it will do another half rotation anti-clockwise. It will be a to-and-fro rotation where the motor comes back after every 180 degrees.

## 2. Positional Relationship of rotor and magnets

Looking at Table 1.2 we can understand the we get can get highest rpm from motor only when at the starting position, the angle is at 0 degrees or 180 degrees (for 180 degrees, direction of motor is opposite). At this angle, the coil and brushes are oriented in the neutral position. At this angle the armature coil winding is perpendicular to the magnetic field lines.

### **K2 Enter the rotational speed Measurement results.**

1. We have recorded the data in Table 1.1. The rotational speed that was determined from the oscilloscope seems more accurate compared to the one determined from the DC motor control board. The reason is that the oscilloscope is able to count complete cycles and we can see the square waves on the screen. On the other hand, the board counts every time the fan/disk crosses the photointerrupter, it counts each rotation very fast. Moreover, the rotations it counts are per 0.42 seconds which is a very small duration. Further, board counts the rotations in binary

representing values 0 to 16 in numbers. The board does not take into account decimal digits. It cannot count in decimal, only counts integers. Lastly, there is a higher possibility of human error while counting from the board. This is because lights blink and it becomes hard to accurately determine the speed. Hence, the oscilloscope is more accurate.

2. In order to improve the accuracy of the motor control board we can do a number of things. Firstly, we can configure the board to measure rotations for long time. Currently the board measures rotations per 0.42 seconds. However, if we increase this time interval then the accuracy can be increased.

Another way to improve the accuracy is to change the shape of the disk. Currently we're using a semicircular disk. If we change the shape to something like fan with two quarters of the disk cut on the diagonals. In this way after every 90 degree rotation the output of the photointerrupter would change because if for first 90 degrees there is some part of the disk, then after that there will be no disk part and then after another 90 degrees there will be the second disk part and in the last 90 degrees there will be the hollow part and then it would continue rotating like that. This will help improve accuracy of counting because our control board counts in very short intervals.



## Week 2

# Brushless DC Motor

### 2.1 Velocity Characteristics Measurement

We begin by removing the brush (making sure that the four brushes are not touching the armature coil of the motor). Then we make some changes in the circuit, to make a brushless DC motor. We configure the motor circuit according to the circuit given in Figure 2.1. The new connections made help in changing the direction of voltage output to the motor according to changes in signals from the encoder which sends signals based on detection from photointerrupter.




Fig. 10: Connection of motor, DC motor control board, and power supply.

Figure 2.1: Connection of motor, DC motor control board, and power supply

#### 2.1.1 Assignment K3

1. After making the connections, we connect the different terminals to observe the wave characteristics on the oscilloscope and see the voltage.

Table 2.1: Relationship between light shielding plate position and voltage at terminals A and B

Light Shielding Plate	A [V]	B [V]	Direction of Voltage
Present	$783.8 \times 10^{-3}$	3.385	B $\rightarrow$ A
Not Present	3.385	$783.810^{-3}$	A $\rightarrow$ B

We find how there are differences in voltages when a light shielding plate exists or not. We also check the characteristics at both terminals A and B. The data is recorded in Table 2.1.

2. The light shielding plate plays a crucial role in changing the direction of voltage. This makes the motor rotate. It is very crucial.
3. There are many reasons why a brushless motor is more effective compared to a brushed motor.
  - There is no friction due to brushes in a brushless motor. This makes rotation smooth and without any constraint.
  - The connection between motor and brush doesn't matter. In the case of brushed motor, it is important that the brushes are touching the motor at all times. If this connection is not proper then there may be some problems.
  - In the case of brushed motor there are sparks or shorting on the brushes. This is not good. On the other hand, there is no such shorting in brushless motor.
  - In the case of brushless motor there is no heat loss from the system. Thus energy is not wasted, this makes the brushless motor more efficient than brushed motor.

Now we make adjustments to our system so that the straight-line part of the semicircular disk is perpendicular to the floor surface when in this state. The orientation of this disk with the motor plays a crucial role in determining motor rotation characteristics. We see that on making this adjustment our motor begins to rotate.

Next we check rotation of motor at different alignment of the semicircular disk. We consider the present position as 0 degrees and get the rotation data for -90 degrees, -45 degrees, 0 degrees, 45 degrees and 90 degrees in Table 2.2.

### 2.1.2 Assignment K4

1. Using the data obtained from our experiments we draw a graph for rpm values of the different angles as in Figure 2.2. We can see that the RPM value is maximum for the case when angle of orientation of the semicircular disk is 90 degrees.




Figure 2.2: RPM Values for Different Angles of orientation of the semicircular disk for a brushless DC motor

2. Since for our brushless DC motor the frequency of rotation is very high, therefore, we can approximate the square wave for the rotations to a sine wave as follows: Consider

$$V = V_0 \sin(\omega t).$$

Due to the inductor coil there will be a self induced emf because current in coil is changing which causes a change in electric field (time varying electric field generates emf, we know this by Faraday's Law)

But

$$V + V_L = 0,$$

where  $V_L$  is induced emf.

$$-L \frac{dI}{dt} = V_L \quad (2.1)$$

$$-L \frac{dI}{dt} + V_0 \sin(\omega t) = 0 \quad (2.2)$$

$$L \int dI = \int V_0 \sin(\omega t) dt \quad (2.3)$$

$$LI = -\frac{V_0}{\omega} \cos(\omega t) \quad (2.4)$$

$$I(t) = \frac{V_0}{\omega L} \sin(\omega t - \frac{\pi}{2}) \quad (2.5)$$

Thus we can see that in the case of a brushless DC motor the current lags the voltage by 90 degrees. So, in order to compensate for this delay in current the light shielding plate is set to 90 degrees, this helps in compensating the delay of current and we get maximum rpm.

3. No the optimal rotor angle of brushed motor did not equal the angle of the light shielding plate at which the rotational speed was at its maximum. The frequency of a brushless DC motor is very high so we can approximate the square waves to sine waves. In a brushed DC motor we saw that the current was changing direction every half a rotation and the maximum rpm was achieved when the angle of orientation was 0 degrees. But for a brushless motor, we see that 90 degrees is maximum, but why? The reason is that since current lags the voltage by 90 degrees we need to compensate that lag. This is why when the orientation is 90 degrees in a brushless motor, the exact same situation as when the angle is 0 degrees in brushed DC motor is achieved. This ensures maximum rpm.

## 2.2 Feedback Based Control System Configuration

In this section we make some changes to the wiring to add a feedback loop to our motor. We aim to understand Rotational Speed Control for a brushless DC motor using Feedback through these experiments.

Table 2.2: Revolutions per Minute of the brushless motor for Different Angles of the Light Shielding Plate

	<b>Revolutions per Minute</b>				
<b>Voltage</b>	Angle 0	Angle -90	Angle -45	Angle 45	Angle 90
1	0	0	0	0	0
2	0	0	0	0	0
3	0	0	0	0	0
4	0	0	0	0	0
5	0	0	0	0	0
6	0	0	0	0	285.7142857
7	142.8571429	0	285.7142857	0	571.4285714
8	285.7142857	0	428.5714286	0	857.1428571
9	285.7142857	0	428.5714286	142.8571429	1000
10	428.5714286	0	571.4285714	428.5714286	1000
11	428.5714286	0	571.4285714	571.4285714	1000
12	571.4285714	0	714.2857143	714.2857143	1000
13	571.4285714	0	714.2857143	857.1428571	1000
14	714.2857143	0	857.1428571	1000	1000
15	714.2857143	0	857.1428571	1000	1000
16	714.2857143	0	1000	1000	1000
17	857.1428571	0	1000	1285.714286	1000
18	1142.857143	0	1142.857143	1142.857143	1285.714286
19	1285.714286	0	1285.714286	1285.714286	1857.142857
20	1428.571429	0	1285.714286	2000	2142.857143

### 2.2.1 Assignment K5

1. I have checked and confirmed that the voltage supplied from the power supply output terminals changes when the values shown by the LED change.
2. In this experiment we recorded the data for RPM corresponding to when the voltage is falling from HIGH to LOW in Table 2.4 and the data corresponding to RPM for when the voltage is rising from LOW to HIGH in Table 2.3. For this data, we recorded the values in every 10 seconds.
3. Next, we plot our data for both the cases on a graph. Figure 2.3 represents the relationship of revolutions per minute with time for both cases and Figure 2.4 represents the relationship of voltage with time. We can see the trend of the graph and we understand the HIGH and LOW values for our system.




Figure 2.3: Plot illustrating relationship between Revolutions per minute and Time for when the voltage is rising (LOW to HIGH) and falling (HIGH to LOW)

Table 2.3: RPM versus Voltage (Low to High)

Voltage [V]	Time [s]	Revolutions per 0.42 seconds	RPM (Low to High)
7	0	2	285.7142857
8	10	3	428.5714286
8.5	20	4	571.4285714
9	30	5	714.2857143
9.5	40	6	857.1428571
10	50	7	1000
10.5	60	7	1000
11	70	8	1142.857143
11.5	80	8	1142.857143
12	90	8	1142.857143
12.5	100	8	1142.857143
12.5	110	8	1142.857143
12.5	120	8	1142.857143
12.5	130	8	1142.857143
12.5	140	8	1142.857143
12.5	150	8	1142.857143
12.5	160	8	1142.857143
12.5	170	8	1142.857143
12.5	180	8	1142.857143
12.5	190	8	1142.857143

Table 2.4: RPM versus Voltage (High to Low)

Voltage [V]	Time [s]	Revolutions per 0.42 seconds	RPM (High to Low)
10	0	9	1285.714286
9	10	8	1142.857143
8.5	20	7	1000
8	30	6	857.1428571
10.5	40	5	714.2857143
7	50	5	714.2857143
7	60	5	714.2857143
7	70	5	714.2857143
7	80	5	714.2857143
7	90	5	714.2857143
7	100	5	714.2857143
7	110	5	714.2857143
7	120	5	714.2857143
7	130	5	714.2857143
7	140	5	714.2857143
7	150	5	714.2857143
7	160	5	714.2857143
7	170	5	714.2857143
7	180	5	714.2857143
7	190	5	714.2857143






Figure 2.4: Plot illustrating relationship between Voltage and Time for when voltage is rising (LOW to HIGH) and falling (HIGH to LOW)

## 2.3 Using Motor as a generator

In this section we will see how to use a motor as a generator. First we will take two motors, and make a connection between motor and generator. A generator also works on the same principles as a motor. We take the motor that we had made and join it using cellophane tape to another motor as in Figure 2.5. The principle used in a generator is that the mechanical energy is converted into electricity. We initially provide some sort of mechanical energy, a small rotation which causes the magnetic field to change. This generates an electric field through the circuit by Faraday's Law. Hence providing voltage. We first rotate the driver motor and observe the voltage generated by the generator with the oscilloscope.

### 2.3.1 Assignment K6

In order to observe the induced voltage we need to connect the oscilloscope terminals to the points encircled in Figure 2.5. These are the terminals of the generator that are connected to the coils in which the voltage is induced. The right side is the motor that we made, using this motor we rotate the generator (the one on the left) and this rotation causes changes in magnetic field which leads to induction of voltage in the coils. And we can measure




Figure 2.5: Connection of Motor and Generator

this induced voltage by observing the aforementioned terminals.

### 2.3.2 Assignment K7

Here we observed waveforms generated by the oscilloscope for three different voltages and rotational speeds. We record the induced voltage values for comparison, see Table 2.5. We have also saved the waveforms for this data

Table 2.5: Data obtained for the induced voltages for 3 different rotational speeds and supply voltages

Supply Voltage [V]	Revolutions per 0.42 seconds	RPM	Induced Voltage [V]
9	3	428.5714286	1.375
15	8	1142.857143	4.026
19	10	1428.571429	4.62

as follows in Figures 2.6, 2.7 and 2.8.

### 2.3.3 Assignment K8

We have plotted the relationship between the rotational speed and induced voltage of the generator waveform that we observed in Assignment K7 in Figure 2.9. We can see that as RPM increases induced voltage also increases,



Figure 2.6: Generator Oscilloscope Waveform for induced voltage when supply voltage is 9V




Figure 2.7: Generator Oscilloscope Waveform for induced voltage when supply voltage is 15V




Figure 2.8: Generator Oscilloscope Waveform for induced voltage when supply voltage is 19V




Figure 2.9: Relationship between rotational speed and induced voltage for the generator

this is straightforward from Electromagnetic Induction.

We know that

$$V = -N \frac{d\Phi}{dt},$$

where  $\Phi$  is the magnetic flux. Also,

$$\Phi = \mathbf{B} \cdot \mathbf{S},$$

where  $\mathbf{B}$  is the magnetic field density and  $\mathbf{S}$  is the surface area vector.

$$\text{Therefore, } V = -N \frac{d}{dt}(\mathbf{B} \cdot \mathbf{S}) \quad (2.6)$$

$$V = -N \frac{d}{dt}(|B||S|\cos\omega t) \quad (2.7)$$

$$V = N|B||S|\omega \sin(\omega t) \quad (2.8)$$

Thus we get an expression for the Induced Voltage. If we look at this expression we can see that this induced voltage will be maximum when  $\sin(\omega t)$  is maximised. Thus,

$$V_{max} = 2\pi f N |B| |S| \quad (2.9)$$

## 2.4 Conclusion

The series of experiments provided valuable insights into the fundamental principles of DC motor manufacture and control. We learned about the physical structures of brushed and brushless DC motors. The hands-on experiences allowed for practical application of theoretical knowledge, reinforcing concepts such as Electromagnetic Induction, Faraday's Law etc. We learned about all the different things that can influence motor rotation characteristics.

# List of Figures

1.1	The four stages of rotation for a brushed DC motor . . . . .	5
2.1	Connection of motor, DC motor control board, and power supply	8
2.2	RPM Values for Different Angles of orientation of the semicircular disk for a brushless DC motor . . . . .	10
2.3	Plot illustrating relationship between Revolutions per minute and Time for when the voltage is rising (LOW to HIGH) and falling (HIGH to LOW) . . . . .	13
2.4	Plot illustrating relationship between Voltage and Time for when voltage is rising (LOW to HIGH) and falling (HIGH to LOW) . . . . .	16
2.5	Connection of Motor and Generator . . . . .	17
2.6	Generator Oscilloscope Waveform for induced voltage when supply voltage is 9V . . . . .	18
2.7	Generator Oscilloscope Waveform for induced voltage when supply voltage is 15V . . . . .	18
2.8	Generator Oscilloscope Waveform for induced voltage when supply voltage is 19V . . . . .	19
2.9	Relationship between rotational speed and induced voltage for the generator . . . . .	19

# List of Tables

1.1	Revolutions per minute (rpm) measured from motor control board and oscilloscope at different voltages . . . . .	3
1.2	Revolutions per minute corresponding to different positions of the rotor notch by adjusting angles . . . . .	4
2.1	Relationship between light shielding plate position and voltage at terminals A and B . . . . .	9
2.2	Revolutions per Minute of the brushless motor for Different Angles of the Light Shielding Plate . . . . .	12
2.3	RPM versus Voltage (Low to High) . . . . .	14
2.4	RPM versus Voltage (High to Low) . . . . .	15
2.5	Data obtained for the induced voltages for 3 different rotational speeds and supply voltages . . . . .	17